

INDUCTANCE

Ranges: 2mH, 20mH, 200mH, 2H, 20H
Accuracy: $\pm(5.0\% \text{rdg} + 20\text{dgt})$ on 2mH
 $\pm(5.0\% \text{rdg} + 10\text{dgt})$ on other ranges

Test frequency: 200Hz

Test conditions: quality factor > 5 in 200Hz

FREQUENCY (Autorange)

Ranges: 2kHz, 20kHz, 200kHz, 2000kHz, 15MHz

Accuracy: $\pm(0.5\% \text{rdg} + 1\text{dgt})$ on all ranges

Sensitivity: 1.0Vrms min.

Overload protection: 500VDC or AC rms

DUTY CYCLE

Ranges: 1.0% to 90.0%

Resolution: 0.1%

Accuracy: $\pm(1.0\% \text{rdg} + 10\text{dgt})$

Pulse Width: >50 μsec ; >20Hz, <20kHz TTL signal

Overload protection: 500VDC or AC rms

TRANSISTOR hFE

Ranges: 0 - 1000

Base current: 10 μA ;dc approx. ($V_{ce}=3.0\text{Vdc}$)

Capacitance & Inductance Measurements

1. Set the Function/Range switch to the desired Cx (capacitance) or Lx (inductance) range.
2. Never apply an external voltage to the Cx Lx sockets. Damage to the meter may result.
3. Insert the capacitor or inductance leads directly into the Cx Lx socket.
4. Read the capacitance or inductance directly from the display.

Transistor Gain Measurements

1. Set the Function/Range switch to the desired hFE range (PNP or NPN type transistor).
2. Never apply an external voltage to the hFE sockets. Damage to the meter may result.
3. Plug the transistor directly into the hFE socket. These sockets are labeled E, B, and C for emitter, base, and collector.
4. Read the transistor hFE (dc gain) directly from the display.

Frequency Measurements

1. Set the Function/Range switch to the Hz position.
2. Connect the red test lead to the "VQ" jack and the black test lead to the "COM" jack.
3. Connect the test leads to the point of measurement and read the frequency from the display.

OPERATION

Before taking any measurements, read the Safety Information Section. Always examine the instrument for damage, contamination (excessive dirt, grease, etc.) and defects. Examine the test leads for cracked or frayed insulation. If any abnormal conditions exist do not attempt to make any measurements.

Max. Hold Feature

Press "MAX" to toggle in and out of the Maximum Hold mode (holding the highest reading.) In the MAX mode, the MAX annunciator is displayed and maximum reading are stored in display register. If the new reading is higher than the reading being displayed, the higher reading is transferred to the display register. A "higher" reading is defined as the reading with the higher absolute value.

The MAX hold function is also available in the frequency count mode. The counter autorangeing feature is disable when MAX hold is selected.

Duty Cycle Measurements

1. Set the Function/Range switch to the DUTY% position.
2. Connect the red test lead to the "VQ" jack and the black test lead to the "COM" jack.
3. Connect the test leads to the point of measurement. The display will indicate 1.0% to 90.0% of the frequency duty cycle.

Voltage Measurements

1. Connect the red test lead to the "VQ" jack and the black test lead to the "COM" jack.
2. Set the Function/Range switch to the desired voltage range and press the "AC/DC" switch to toggle between the desired voltage type. If magnitude of voltage is not known, set switch to the highest range and reduce until a satisfactory reading is obtained.
3. Connect the test leads to the device or circuit being measured.
4. For dc, a (-) sign is displayed for negative polarity; positive polarity is implied.

Current Measurements


1. Set the Function/Range switch to the desired current range and press the "AC/DC" switch to toggle between to the desired current type.
2. For current measurements less than 200mA, connect the red test lead to the mA jack and the black test lead to the COM jack.
3. For current measurements of 200mA or greater, connect the red test lead to the 20A jack and the black test lead to the COM jack.
4. Remove power from the circuit under test and open the normal circuit path where the measurement is to be taken. Connect the meter in series with the circuit.

MAINTENANCE

WARNING

Remove test leads before changing battery or fuse or performing any servicing.

Battery Replacement

Power is supplied by a 9 volt "transistor" battery. (NEDA 1604 IEC 6F22). The "  " appears on the LCD display when replacement is needed. To replace the battery, remove the two screws from the back of the meter and lift off the battery case. Remove the battery from battery contacts.


Fuse Replacement

If no current measurements are possible, check for a blown overload protection fuse. There are two fuses; F1 for the "mA" jack and F2 for the "20A" jack. For access to fuses, remove the two screws from the back of the meter and lift off the battery case. Replace F1 only with the original type 0.5A/250V, fast acting fuse. Replace F2 only with the original type 20A/600V, fast acting ceramic fuse.

Resistance and Continuity Measurements

1. Set the Function/Range switch to the desired resistance range or continuity position.
2. Remove power from the equipment under test.
3. Connect the red test lead to the "VQ" jack and the black test lead to the "COM" jack.
4. Touch the probes to the test points. In ohms, the value indicated in the display is the measured value of resistance. In continuity test, the beeper sounds continuously, if the resistance is less than 40 Ω \pm 20 Ω .

Diode Tests

1. Connect the red test lead to the "VQ" jack and the black test lead to the "COM" jack.
2. Set the Function/Range switch to the "  " position.
3. Turn off power to the circuit under test.
4. Touch probes to the diode. A forward-voltage drop is about 0.6V (typical for a silicon diode).
5. Reverse probes. If the diode is good, "OL" is displayed. If the diode is shorted, ".000" or another number is displayed.
6. If the diode is open, "OL" is displayed in both directions.
7. If the junction is measured in a circuit and a low reading is obtained with both lead connections, the junction may be shunted by a resistance of less than 1k Ω . In this case the diode must be disconnected from the circuit for accurate testing.

20 CALIBRATION PROCEDURE

The procedure should be performed at an ambient temperature of $25\text{ }^{\circ}\text{C} \pm 2\text{ }^{\circ}\text{C}$, and at a relative humidity of less than 75 % .

A. DCV Calibration

- Set the range to the “200mv” position .
- Set the output of the DC calibrator for $190\text{mv} \pm 0.02\%$. and connect it to the “V- Ω ” , and “COM” input jacks .
- Slowly adjust the “R44” until the display reads $190.0\text{mv} \pm 1$ digit .
- Carefully inspect the other DCV ranges, your reading should be within the specification of instruction manual .
- There is no adjustable parts for the ACV range, your reading should be within the specification of instruction manual .

B. DCA Calibration

- Set the range to the “20A” position .
- Set the output of the DC calibrator for $1.9\text{A} \pm 0.02\%$. and connect it to the “20A” , and “COM” input jacks .
- Adjust “Shunt resistance” until the display reads 1.9A,if the reading is over 1.9A, add solder onto Shunt resistance , on the contrary the reading is under 1.9A, shave away some of solder from it ,carefully inspect the other ranges , your reading should be within the spec of instruction manual .

C. Capacitance and Inductance calibration



ZERO adjustment

- Set the range to the “2mH” position, and shorting Lx jacks .
- Slowly adjust the “R520” until the display reads 000.0 .

ACCURACY adjustment








- Set the range to the “200NF” position, and using 100NF capacitor to adjust R55 until the display reads 100NF .
- Set the range to the “200UF” position, and using 100UF capacitor to adjust R551 until the display reads 100UF .

MODEL: 20SMD









NOTE: UNLESS OTHERWISE SPECIFIED
 1. ALL RESISTANCE VALUES IN OHMS
 2. ALL CAPACITANCE VALUES IN MICROFARADS
 3. ALL THE COMPONENTS ARE MARKED WITH * * *
 THAT VALUES IS VARIABLE.

文件編號	RC-0020S-S	料號	0020S-S.DWG	CHY 連虹股份有限公司
文件名稱	20SMD 線路圖	圖號	0020S-S.DWG	TEL: (06)2794811 FAX: (06)2700227
版	第 1 版	頁	第 1 頁	共 2 頁



U70 74HC14



文件編號	RC-0020S-S1	料號	0020S-S1.DWG
文件名稱	20SMD 線路圖	圖號	0020S-S1.DWG
版本	第 1 版 第 3 次	頁次	第 2 頁 共 2 頁

CHY 連虹股份有限公司
 TEL (06)2794811 FAX (06)2700227

審核	85.5.16
核准	85.5.15
備註	85.5.15
日期	85.5.15
地點	85.5.15